Wireless Charge pad fits in the open ashtray of the X150 XK/XKR models, ideal if you are using wireless CarPlay or wireless Android Auto.

15W Aerpro brand charge pad, with a matt black non-slip silicone top so your phone doesn't slide around.



Includes the USB cables and USB power adaptor.



Installation

Slide the ashtray lid open all the way.

Remove the ashtray insert



Plug in the power adaptor and set the USB cable in the ashtray



Place the charge pad in the opening, tucking the cable underneath.



The spring force of the ashtray lid will hold it in place.

Contact

email: info@oldjaguar.com for technical support or purchasing.